Product Safety Information

Manufacturer

Manufacturer: Bushcraft Essentials GmbH

Address: Friedrichstr. 19, 85435 Erding, Germany

Contact: info@bushcraft-essentials.com

Product information

Product Name: Wood Slide Bushbox XXL+

Model Number: BCE-073 / EAN:4260365160733

Description:

The Wood Slide enhances your cooking experience and enjoyment of the fire by automatically feeding firewood into the fire chamber of your Bushbox XXL+. There's no need for constant wood additions; simply feed longer branches from the start and focus on cooking or relaxing by the fire.

The „Wood Slide Bushbox XXL+“ in detail

- The Wood Slide is easily inserted through the fuel window at a slight angle and then positioned horizontally (see photos).
- You can adjust the angle of inclination using the attached chain by hooking it into the two outermost hooks at the top. For longer and heavier branches, a steeper angle (i.e. a shorter chain) ensures the wood slides down reliably and the Bushbox remains stable, preventing accidental tipping.
- Light your Bushbox fire as usual and add the appropriate amount of fuel. Once the fire starts, you can add wood through the Wood Slide. The wood will automatically slide in as the fire burns, so you don't need to constantly add burnable material. Meanwhile, you can prepare food on the Bushbox using our Trivets or Universal Grate.
- Alternatively, if the angle is very shallow, you can use the Wood Slide as a small platform to keep your drink warm.
- You can also hook the Wood Slide vertically into the stove from the inside (see photo) to completely close the fuel window. This is useful for making a campfire, as it allows the heat to radiate all the way up. Alternatively, you could cook with charcoal or use it as an additional windshield for your Trangia.
- Caution: The chain is designed to withstand high temperatures, even when hanging in the combustion chamber. However, never touch it with bare hands when hot. Always wear gloves.
- Note: Occasionally, you may need to manually nudge the wood further in to ensure it burns evenly and does not accidentally ignite outside the Bushbox.

Technical data

- Dimensions: 15.5 x 15 cm
- Weight: 184 g (100 % stainless steel)

- Made in Germany

OTHER PRODUCTS SHOWN ARE INTENDED FOR ILLUSTRATIVE PURPOSES ONLY AND ARE NOT PART OF THE OFFER.

HS code: 732119

Product category: solid fuel non-electric stoves

Product image:



Description

The Wood Slide enhances your cooking experience and enjoyment of the fire by automatically feeding firewood into the fire chamber of your Bushbox XXL+. There's no need for constant wood additions; simply feed longer branches from the start and focus on cooking or relaxing by the fire.

The „Wood Slide Bushbox XXL+“ in detail

- The Wood Slide is easily inserted through the fuel window at a slight angle and then positioned horizontally (see photos).
- You can adjust the angle of inclination using the attached chain by hooking it into the two outermost hooks at the top. For longer and heavier branches, a steeper angle (i.e. a shorter chain) ensures the wood slides down reliably and the Bushbox remains stable, preventing accidental tipping.
- Light your Bushbox fire as usual and add the appropriate amount of fuel. Once the fire starts, you can add wood through the Wood Slide. The wood will automatically slide in as the fire burns, so you don't need to constantly add burnable material. Meanwhile, you can prepare food on the Bushbox using our Trivets or Universal Grate.
- Alternatively, if the angle is very shallow, you can use the Wood Slide as a small platform to keep your drink warm.
- You can also hook the Wood Slide vertically into the stove from the inside (see photo) to completely close the fuel window. This is useful for making a campfire, as it allows the heat to radiate all the way up. Alternatively, you could cook with charcoal or use it as an additional windshield for your Trangia.
- Caution: The chain is designed to withstand high temperatures, even when hanging in the combustion chamber. However, never touch it with bare hands when hot. Always wear gloves.
- Note: Occasionally, you may need to manually nudge the wood further in to ensure it burns evenly and does not accidentally ignite outside the Bushbox.

Technical data

- Dimensions: 15.5 x 15 cm
- Weight: 184 g (100 % stainless steel)
- Made in Germany

OTHER PRODUCTS SHOWN ARE INTENDED FOR ILLUSTRATIVE PURPOSES ONLY AND ARE NOT PART OF THE OFFER.

Safety Instructions:

- **Usage Instructions:**
  - Use only outdoors.
  - Ensure the stove and its accessories are placed on a stable, level, and fireproof surface.
  - Keep the product away from flammable materials during operation.
  - Avoid flying sparks: Flying sparks can cause fires or burn holes in plastic materials (tents, clothing).
- **Fuel:**
  - Use only recommended fuels (twigs, branches, alcohol burners, fuel paste).
  - Do not use liquid fuels such as gasoline or alcohol that are not explicitly recommended.
- **Operation:**
  - Never leave an open fire unattended.
  - Use heat-resistant gloves to avoid burns.
  - Ensure the product has cooled down completely before touching, disassembling or storing it.
  - Observe the local regulations for open fire.
- **Children and Pets:**
  - Keep children and pets away from the product while it is in use.
  - Store the product out of reach of children.
- **Maintenance and Care:**
  - Clean the products after each use.
  - Regularly check for damage or wear and replace damaged parts immediately.

Emergency Measures:

- In case of fire: Use a fire extinguisher or sand to extinguish the fire. Do not use water if the stove and its accessories are operated with alcohol.
- In case of burns: Cool the affected area immediately with cold water and seek medical attention.

Place and date

Place: Erding

Date: September 4, 2026