Product Safety Information

Manufacturer

Manufacturer: Bushcraft Essentials GmbH

Address: Friedrichstr. 19, 85435 Erding, Germany

Contact: info@bushcraft-essentials.com

Product information

Product Name: Flip Plate Bushbox XL

Model Number: BCE-081 / EAN:4260365160818

Description:

The Flip Plate Bushbox XL is a dual-sided accessory for your Bushbox XL.

Placed on top of the stove, it serves as a robust frying or grill plate, ideal for frying, grilling and roasting over an open fire. Its slightly curved shape keeps food securely in place and prevents it from slipping off or fat from dripping into the fire.

When you turn the Flip Plate over, it serves as ground protection and a stable base for your Bushbox XL. It protects the surface underneath from heat, embers and ash—especially important on sensitive or dry ground.

The Flip Plate Bushbox XL can also be used as a dry base for fire-making or food preparation.

Usage tips:

- The plate can be placed on and removed using the Bushbox XL Trivets. Wear gloves, as the Flip Plate becomes very hot.
- Use a high-heat cooking oil for grilling and frying.
- When operating the stove with the plate on top, use charcoal (or pellets). This ensures moderate, even heat. When using wood, there is a risk of overheating.

The Flip Plate Bushbox XL is robust, heat-resistant and designed for long-term outdoor use. Nevertheless, uneven heating (e.g. due to wind or the quantity and type of fuel) may cause minimal warping, which does not affect the functionality of the Flip Plate.

Technical data

- Weight: approx. 190 g
- Dimensions: 14.3 x 13.7 x 1 cm
- Material: 100 % stainless steel
- Made in Germany

OTHER PRODUCTS SHOWN ARE INTENDED FOR ILLUSTRATIVE PURPOSES ONLY AND ARE NOT PART OF THE OFFER.

HS code: 732119

Product category: solid fuel non-electric stoves

Product image:



Description

The Flip Plate Bushbox XL is a dual-sided accessory for your Bushbox XL.

Placed on top of the stove, it serves as a robust frying or grill plate, ideal for frying, grilling and roasting over an open fire. Its slightly curved shape keeps food securely in place and prevents it from slipping off or fat from dripping into the fire.

When you turn the Flip Plate over, it serves as ground protection and a stable base for your Bushbox XL. It protects the surface underneath from heat, embers and ash—especially important on sensitive or dry ground.

The Flip Plate Bushbox XL can also be used as a dry base for fire-making or food preparation.

Usage tips:

- The plate can be placed on and removed using the Bushbox XL Trivets. Wear gloves, as the Flip Plate becomes very hot.
- Use a high-heat cooking oil for grilling and frying.
- When operating the stove with the plate on top, use charcoal (or pellets). This ensures moderate, even heat. When using wood, there is a risk of overheating.

The Flip Plate Bushbox XL is robust, heat-resistant and designed for long-term outdoor use. Nevertheless, uneven heating (e.g. due to wind or the quantity and type of fuel) may cause minimal warping, which does not affect the functionality of the Flip Plate.

Technical data

- Weight: approx. 190 g
- Dimensions: 14.3 x 13.7 x 1 cm
- Material: 100 % stainless steel
- Made in Germany

OTHER PRODUCTS SHOWN ARE INTENDED FOR ILLUSTRATIVE PURPOSES ONLY AND ARE NOT PART OF THE OFFER.

Safety Instructions:

- **Usage Instructions:**
  - Use only outdoors.
  - Ensure the stove and its accessories are placed on a stable, level, and fireproof surface.
  - Keep the product away from flammable materials during operation.
  - Avoid flying sparks: Flying sparks can cause fires or burn holes in plastic materials (tents, clothing).
- **Fuel:**
  - Use only recommended fuels (twigs, branches, alcohol burners, fuel paste).
  - Do not use liquid fuels such as gasoline or alcohol that are not explicitly recommended.
- **Operation:**
  - Never leave an open fire unattended.
  - Use heat-resistant gloves to avoid burns.
  - Ensure the product has cooled down completely before touching, disassembling or storing it.
  - Observe the local regulations for open fire.
- **Children and Pets:**
  - Keep children and pets away from the product while it is in use.
  - Store the product out of reach of children.
- **Maintenance and Care:**
  - Clean the products after each use.
  - Regularly check for damage or wear and replace damaged parts immediately.

Emergency Measures:

- In case of fire: Use a fire extinguisher or sand to extinguish the fire. Do not use water if the stove and its accessories are operated with alcohol.
- In case of burns: Cool the affected area immediately with cold water and seek medical attention.

Place and date

Place: Erding

Date: September 4, 2026