Product Safety Information

Manufacturer

Manufacturer: Bushcraft Essentials GmbH

Address: Friedrichstr. 19, 85435 Erding, Germany

Contact: info@bushcraft-essentials.com

Product information

Product Name: Grill Plate Bushbox / Bushbox Titanium

Model Number: BCE-026 / EAN:4260365160269

Description:

You can either buy the Grill Plate as a separate accessory for your Bushbox or Bushbox Titanium or as part of the Bushbox Set.

The „Grill Plate Bushbox / Bushbox Titanium“ in detail

- The Grill Plate provides a solid platform for smaller pots and cups.
- With the Grill Plate, you can turn your Bushbox into a mini grill.
- Note: The Grill Plate can only be used from the 4th generation of the Bushbox with the notches on the top of the short side panels.

Technical data


- Weight: 35 g
- Dimensions: 8.8 x 8 cm
- Material: 100 % stainless steel (0.8 mm, 1.4301)
- Made in Germany

OTHER PRODUCTS SHOWN ARE INTENDED FOR ILLUSTRATIVE PURPOSES ONLY AND ARE NOT PART OF THE OFFER.

HS code: 732119

Product category: solid fuel non-electric stoves

Product image:



Description

You can either buy the Grill Plate as a separate accessory for your Bushbox or Bushbox Titanium or as part of the Bushbox Set.

The „Grill Plate Bushbox / Bushbox Titanium“ in detail

- The Grill Plate provides a solid platform for smaller pots and cups.
- With the Grill Plate, you can turn your Bushbox into a mini grill.
- Note: The Grill Plate can only be used from the 4th generation of the Bushbox with the notches on the top of the short side panels.

Technical data

- Weight: 35 g
- Dimensions: 8.8 x 8 cm
- Material: 100 % stainless steel (0.8 mm, 1.4301)
- Made in Germany

OTHER PRODUCTS SHOWN ARE INTENDED FOR ILLUSTRATIVE PURPOSES ONLY AND ARE NOT PART OF THE OFFER.

Safety Instructions:

- **Usage Instructions:**
  - Use only outdoors.
  - Ensure the stove and its accessories are placed on a stable, level, and fireproof surface.
  - Keep the product away from flammable materials during operation.
  - Avoid flying sparks: Flying sparks can cause fires or burn holes in plastic materials (tents, clothing).
- **Fuel:**
  - Use only recommended fuels (twigs, branches, alcohol burners, fuel paste).
  - Do not use liquid fuels such as gasoline or alcohol that are not explicitly recommended.
- **Operation:**
  - Never leave an open fire unattended.
  - Use heat-resistant gloves to avoid burns.
  - Ensure the product has cooled down completely before touching, disassembling or storing it.
  - Observe the local regulations for open fire.
- **Children and Pets:**
  - Keep children and pets away from the product while it is in use.
  - Store the product out of reach of children.
- **Maintenance and Care:**
  - Clean the products after each use.
  - Regularly check for damage or wear and replace damaged parts immediately.

Emergency Measures:

- In case of fire: Use a fire extinguisher or sand to extinguish the fire. Do not use water if the stove and its accessories are operated with alcohol.
- In case of burns: Cool the affected area immediately with cold water and seek medical attention.

Place and date

Place: Erding

Date: September 4, 2026