Product Safety Information

Manufacturer

Manufacturer: Bushcraft Essentials GmbH

Address: Friedrichstr. 19, 85435 Erding, Germany

Contact: info@bushcraft-essentials.com

Product information

Product Name: Trivet Bushbox Ultralight

Model Number: BCE-028 / EAN:4260365160283

Description:

Our Bushbox Ultralight comes with a Trivet as standard. If you need an additional Trivet or have misplaced yours, you can order one here.

The „Trivet Bushbox Ultralight“ in detail

- The Trivet provides additional stability for the stove.
- On top of the Bushbox Ultralight it ensures safe standing for cups and cooking vessels of almost any size.
- The total weight of the Bushbox Ultralight can be reduced if you replace the Base Plate by a second Trivet (as a lightweight base for the Trangia burner).
- The holes in the Trivet ensure a sufficient air supply between flame and cookware.

Technical data

- Weight: 7 g
- Dimensions: 8.5 x 6 cm
- Material: 100 % stainless spring steel
- Made in Germany

OTHER PRODUCTS SHOWN ARE INTENDED FOR ILLUSTRATIVE PURPOSES ONLY AND ARE NOT PART OF THE OFFER.

HS code: 732119

Product category: solid fuel non-electric stoves

Product image:



Description

Our Bushbox Ultralight comes with a Trivet as standard. If you need an additional Trivet or have misplaced yours, you can order one here.

The „Trivet Bushbox Ultralight“ in detail

- The Trivet provides additional stability for the stove.
- On top of the Bushbox Ultralight it ensures safe standing for cups and cooking vessels of almost any size.
- The total weight of the Bushbox Ultralight can be reduced if you replace the Base Plate by a second Trivet (as a lightweight base for the Trangia burner).
- The holes in the Trivet ensure a sufficient air supply between flame and cookware.

Technical data

- Weight: 7 g
- Dimensions: 8.5 x 6 cm
- Material: 100 % stainless spring steel
- Made in Germany

OTHER PRODUCTS SHOWN ARE INTENDED FOR ILLUSTRATIVE PURPOSES ONLY AND ARE NOT PART OF THE OFFER.

Safety Instructions:

- **Usage Instructions:**
  - Use only outdoors.
  - Ensure the stove and its accessories are placed on a stable, level, and fireproof surface.
  - Keep the product away from flammable materials during operation.
  - Avoid flying sparks: Flying sparks can cause fires or burn holes in plastic materials (tents, clothing).
- **Fuel:**
  - Use only recommended fuels (twigs, branches, alcohol burners, fuel paste).
  - Do not use liquid fuels such as gasoline or alcohol that are not explicitly recommended.
- **Operation:**
  - Never leave an open fire unattended.
  - Use heat-resistant gloves to avoid burns.
  - Ensure the product has cooled down completely before touching, disassembling or storing it.
  - Observe the local regulations for open fire.
- **Children and Pets:**
  - Keep children and pets away from the product while it is in use.
  - Store the product out of reach of children.
- **Maintenance and Care:**
  - Clean the products after each use.
  - Regularly check for damage or wear and replace damaged parts immediately.

Emergency Measures:

- In case of fire: Use a fire extinguisher or sand to extinguish the fire. Do not use water if the stove and its accessories are operated with alcohol.
- In case of burns: Cool the affected area immediately with cold water and seek medical attention.

Place and date

Place: Erding

Date: September 4, 2026