Product Safety Information

Manufacturer

Manufacturer: Bushcraft Essentials GmbH

Address: Friedrichstr. 19, 85435 Erding, Germany

Contact: info@bushcraft-essentials.com

Product information

Product Name: Ash Plate Bushbox Ultralight

Model Number: BCE-030 / EAN:4260365160306

Description:

If you like to use your Bushbox Ultralight in hobo mode (with wood), we recommend using this Ash Plate to protect the ground.

The „Ash Plate Bushbox Ultralight“ in detail

- If the Bushbox Ultralight is operated with wood in hobo mode, we recommend using the Ash Plate. It helps to protect the soil and prevents embers from falling onto the ground and causing a fire.
- The Ash Plate can be inserted into the Bushbox Ultralight in three different positions.

Technical data

- Weight: 14 g
- Dimensions: 9 x 9 cm
- Material: 100 % stainless spring steel
- Made in Germany

OTHER PRODUCTS SHOWN ARE INTENDED FOR ILLUSTRATIVE PURPOSES ONLY AND ARE NOT PART OF THE OFFER.

HS code: 732119

Product category: solid fuel non-electric stoves

Product image:



Description

If you like to use your Bushbox Ultralight in hobo mode (with wood), we recommend using this Ash Plate to protect the ground.

The „Ash Plate Bushbox Ultralight“ in detail

- If the Bushbox Ultralight is operated with wood in hobo mode, we recommend using the Ash Plate. It helps to protect the soil and prevents embers from falling onto the ground and causing a fire.
- The Ash Plate can be inserted into the Bushbox Ultralight in three different positions.

Technical data

- Weight: 14 g
- Dimensions: 9 x 9 cm
- Material: 100 % stainless spring steel
- Made in Germany

OTHER PRODUCTS SHOWN ARE INTENDED FOR ILLUSTRATIVE PURPOSES ONLY AND ARE NOT PART OF THE OFFER.

Safety Instructions:

- **Usage Instructions:**
  - Use only outdoors.
  - Ensure the stove and its accessories are placed on a stable, level, and fireproof surface.
  - Keep the product away from flammable materials during operation.
  - Avoid flying sparks: Flying sparks can cause fires or burn holes in plastic materials (tents, clothing).
- **Fuel:**
  - Use only recommended fuels (twigs, branches, alcohol burners, fuel paste).
  - Do not use liquid fuels such as gasoline or alcohol that are not explicitly recommended.
- **Operation:**
  - Never leave an open fire unattended.
  - Use heat-resistant gloves to avoid burns.
  - Ensure the product has cooled down completely before touching, disassembling or storing it.
  - Observe the local regulations for open fire.
- **Children and Pets:**
  - Keep children and pets away from the product while it is in use.
  - Store the product out of reach of children.
- **Maintenance and Care:**
  - Clean the products after each use.
  - Regularly check for damage or wear and replace damaged parts immediately.

Emergency Measures:

- In case of fire: Use a fire extinguisher or sand to extinguish the fire. Do not use water if the stove and its accessories are operated with alcohol.
- In case of burns: Cool the affected area immediately with cold water and seek medical attention.

Place and date

Place: Erding

Date: September 4, 2026