Product Safety Information

Manufacturer

Manufacturer: Bushcraft Essentials GmbH

Address: Friedrichstr. 19, 85435 Erding, Germany

Contact: info@bushcraft-essentials.com

Product information

Product Name: Multifunctional Case Bushbox XL

Model Number: BCE-051 / EAN:4260365160511

Description:

The Multifunctional Case is a sophisticated accessory for all outdoor enthusiasts. It securely stows your Bushbox XL, and the slide-in module offers a wide range of additional uses.

The „Multifunctional Case Bushbox XL“ in detail

- The stainless steel Case easily stows your Bushbox XL cleanly and compactly in your backpack.
- Use it as a fireproof, dry base to make feather sticks or scrape bark to start a fire. The ignited material can be slid directly from the case into your Bushbox.
- Snap your Bushbox XL into the matching recesses to use the Multifunctional Case as stable support. Practical also on uneven terrain such as sand or snow.
- At the same time, the Case protects the ground from hot embers and possible fire residues.
- In your outdoor kitchen, the Multifunctional Case serves as a base for preparing meals or as a lid for your cookware.
- Note: To store your Bushbox XL together with the Multifunctional Case, we recommend our Leather Pouch Bushbox XL instead of the Outdoor Bag. It offers enough space for your stove and accessories.

Technical data

- Weight: 255 g
- Dimensions: 19 x 13 x 1.5 cm
- Material: 100 % stainless steel (1.4301, 1 mm)
- Made in Germany

OTHER PRODUCTS SHOWN ARE INTENDED FOR ILLUSTRATIVE PURPOSES ONLY AND ARE NOT PART OF THE OFFER.

HS code: 732119

Product category: solid fuel non-electric stoves

Product image:



Description

The Multifunctional Case is a sophisticated accessory for all outdoor enthusiasts. It securely stows your Bushbox XL, and the slide-in module offers a wide range of additional uses.

The „Multifunctional Case Bushbox XL“ in detail

- The stainless steel Case easily stows your Bushbox XL cleanly and compactly in your backpack.
- Use it as a fireproof, dry base to make feather sticks or scrape bark to start a fire. The ignited material can be slid directly from the case into your Bushbox.
- Snap your Bushbox XL into the matching recesses to use the Multifunctional Case as stable support. Practical also on uneven terrain such as sand or snow.
- At the same time, the Case protects the ground from hot embers and possible fire residues.
- In your outdoor kitchen, the Multifunctional Case serves as a base for preparing meals or as a lid for your cookware.
- Note: To store your Bushbox XL together with the Multifunctional Case, we recommend our Leather Pouch Bushbox XL instead of the Outdoor Bag. It offers enough space for your stove and accessories.

Technical data

- Weight: 255 g
- Dimensions: 19 x 13 x 1.5 cm
- Material: 100 % stainless steel (1.4301, 1 mm)
- Made in Germany

OTHER PRODUCTS SHOWN ARE INTENDED FOR ILLUSTRATIVE PURPOSES ONLY AND ARE NOT PART OF THE OFFER.

Safety Instructions:

- **Usage Instructions:**
  - Use only outdoors.
  - Ensure the stove and its accessories are placed on a stable, level, and fireproof surface.
  - Keep the product away from flammable materials during operation.
  - Avoid flying sparks: Flying sparks can cause fires or burn holes in plastic materials (tents, clothing).
- **Fuel:**
  - Use only recommended fuels (twigs, branches, alcohol burners, fuel paste).
  - Do not use liquid fuels such as gasoline or alcohol that are not explicitly recommended.
- **Operation:**
  - Never leave an open fire unattended.
  - Use heat-resistant gloves to avoid burns.
  - Ensure the product has cooled down completely before touching, disassembling or storing it.
  - Observe the local regulations for open fire.
- **Children and Pets:**
  - Keep children and pets away from the product while it is in use.
  - Store the product out of reach of children.
- **Maintenance and Care:**
  - Clean the products after each use.
  - Regularly check for damage or wear and replace damaged parts immediately.

Emergency Measures:

- In case of fire: Use a fire extinguisher or sand to extinguish the fire. Do not use water if the stove and its accessories are operated with alcohol.
- In case of burns: Cool the affected area immediately with cold water and seek medical attention.

Place and date

Place: Erding

Date: September 4, 2026