Product Safety Information

Manufacturer

Manufacturer: Bushcraft Essentials GmbH

Address: Friedrichstr. 19, 85435 Erding, Germany

Contact: info@bushcraft-essentials.com

Product information

Product Name: Universal Grate Bushbox XXL+

Model Number: BCE-072 / EAN:4260365160726

Description:

This Universal Grate Bushbox XXL+ is a real all-rounder and can be used in many ways.

The „Universal Grate Bushbox XXL+“ in detail

- With this useful accessory, you can turn your Bushbox XXL+ into a mobile grill in no time at all to easily grill larger steaks, sausages, and vegetables.
- Suitable as a stable stand for cups or other vessels.
- Inserted into a special half-height position, it can be used as a stand for smaller gas cartridges with burner.
- In this half-height position, it is also ideal for the use with charcoal or wood pellets (lower fuel consumption with more effective and constant cooking or grilling temperature over a long period of time; one cup of pellets is enough for approx. 30 minutes of operating time).
- In combination with a pair of Trivets, the Universal Grate can also be used as a toast holder.
- The sides of the Universal Grate have two slots. Here you can insert the Trivets to easily remove the Universal Grate from the hot Bushbox or to place it on top.
- Note: The Universal Grate features a visible cross-shaped bend for added stability. When placing it on the stove, make sure the tip of the bend is pointing upwards. This reduces physical distortion.
- You can store the Universal Grate together with your Bushbox XXL+ in a separate compartment of the matching Outdoor Bag.

Technical data

- Weight: 210 g
- Dimensions: 19.6 x 19 cm
- Material: 100 % stainless steel
- Made in Germany

OTHER PRODUCTS SHOWN ARE INTENDED FOR ILLUSTRATIVE PURPOSES ONLY AND ARE NOT PART OF THE OFFER.

HS code: 732119

Product category: solid fuel non-electric stoves

Product image:



Description

This Universal Grate Bushbox XXL+ is a real all-rounder and can be used in many ways.

The „Universal Grate Bushbox XXL+“ in detail

- With this useful accessory, you can turn your Bushbox XXL+ into a mobile grill in no time at all to easily grill larger steaks, sausages, and vegetables.
- Suitable as a stable stand for cups or other vessels.
- Inserted into a special half-height position, it can be used as a stand for smaller gas cartridges with burner.
- In this half-height position, it is also ideal for the use with charcoal or wood pellets (lower fuel consumption with more effective and constant cooking or grilling temperature over a long period of time; one cup of pellets is enough for approx. 30 minutes of operating time).
- In combination with a pair of Trivets, the Universal Grate can also be used as a toast holder.
- The sides of the Universal Grate have two slots. Here you can insert the Trivets to easily remove the Universal Grate from the hot Bushbox or to place it on top.
- Note: The Universal Grate features a visible cross-shaped bend for added stability. When placing it on the stove, make sure the tip of the bend is pointing upwards. This reduces physical distortion.
- You can store the Universal Grate together with your Bushbox XXL+ in a separate compartment of the matching Outdoor Bag.

Technical data

- Weight: 210 g
- Dimensions: 19.6 x 19 cm
- Material: 100 % stainless steel
- Made in Germany

OTHER PRODUCTS SHOWN ARE INTENDED FOR ILLUSTRATIVE PURPOSES ONLY AND ARE NOT PART OF THE OFFER.

Safety Instructions:

- **Usage Instructions:**
  - Use only outdoors.
  - Ensure the stove and its accessories are placed on a stable, level, and fireproof surface.
  - Keep the product away from flammable materials during operation.
  - Avoid flying sparks: Flying sparks can cause fires or burn holes in plastic materials (tents, clothing).
- **Fuel:**
  - Use only recommended fuels (twigs, branches, alcohol burners, fuel paste).
  - Do not use liquid fuels such as gasoline or alcohol that are not explicitly recommended.
- **Operation:**
  - Never leave an open fire unattended.
  - Use heat-resistant gloves to avoid burns.
  - Ensure the product has cooled down completely before touching, disassembling or storing it.
  - Observe the local regulations for open fire.
- **Children and Pets:**
  - Keep children and pets away from the product while it is in use.
  - Store the product out of reach of children.
- **Maintenance and Care:**
  - Clean the products after each use.
  - Regularly check for damage or wear and replace damaged parts immediately.

Emergency Measures:

- In case of fire: Use a fire extinguisher or sand to extinguish the fire. Do not use water if the stove and its accessories are operated with alcohol.
- In case of burns: Cool the affected area immediately with cold water and seek medical attention.

Place and date

Place: Erding

Date: September 4, 2026